



قطعات

کندانسور واکيوم	19
شیرهای سرویس واکيوم	20
باکس خروجی محلول غلیظ از ژنراتور	21
شیرهای سرویس	22
مبدل حرارتی	23
شیر رقیق کردن دستی	24
تابلوی کنترل الکتریکی	25
شیر تخلیه ژنراتور به ایزوریتر	26
کنترل سطح مبرد	27

چشمی	10
خط محلول رقیق گرم	11
واتریاکسهای ورودی و خروجی به کندانسور	12
واتریاکسهای ورودی و خروجی به ژنراتور	13
واتریاکسهای ورودی و خروجی به اویپراتور	14
واتریاکسهای ورودی و خروجی به ایزوریتر	15
شیر سولونوئید واکيوم	16
پمپ واکيوم	17
مانومتر جیوه ای	18

تانک مبرد	1
خط آبی کریستال اتو ماتیک	2
خط محلول غلیظ گرم	3
پمپ مبرد	4
پمپ محلول	5
اناکتور	6
محلول غلیظ خروج از مبدل	7
خط محلول غلظت متوسط	8
محلول رقیق	9

PARTS

1	Cold Box
2	Automatic Anti Crystal Line
3	Strong Solution Line (Hot)
4	Refrigerant Pump
5	Solution Pump
6	Eductor
7	Strong Solution Line (cold)
8	Intermediate Solution Line
9	Weak Solution Line

10	Sight Glass
11	Weak Solution Line (Hot)
12	Water Box for Condenser
13	Water Box for Generator
14	Water Box for Evaporator
15	Water Box for Absorber
16	Solonoid Valve
17	Vacuum Pump
18	Vacuum Gage

19	Vacuum Condenser
20	Vacuum Service Valves
21	Strong Solution Outlet
22	Service Valves
23	Heat Exchanger
24	Manual dilute Service Valve
25	Control Panel
26	Generator Drain Valve
27	Refrigerant Level Control